VICTORIAN BATHROOM

Essential Renovation & Heritage Planning Checklist

Restoring or replicating a Victorian bathroom requires balancing period authenticity with modern performance. Use this comprehensive checklist to cover key technical, aesthetic, and structural requirements before commencing your project.

1. HERITAGE FEATURES

- [ ] **Wall Panelling:** Assess moisture-resistant MDF or treated timber wainscoting/beadboard.
- [ ] **Period Tiling:** Source authentic encaustic floor tiles or metro/subway wall tiles with dark grout.
- [ ] **Architectural Moldings:** Retain or install period-accurate dado rails, picture rails, and deep coving.
- [ ] **Cast Iron & Brass:** Verify structural floor integrity for heavy cast iron baths or radiators.

2. PERMISSIONS & PLANNING

- [ ] **Listed Building Consent:** Confirm if the property is Listed (Grade I/II) before altering layout or pipework.
- [ ] **Conservation Area:** Check restrictions on external soil vent pipes or extract flues.
- [ ] **Building Regulations:** Ensure compliance for structural modifications, rewiring, and ventilation.
- [ ] **Party Wall Agreements:** Obtain approvals if chasing pipes or embedding structure in shared walls.

3. PLUMBING & WATER SUPPLY

- [ ] **Water Pressure Test:** Check static and dynamic pressure for high-flow traditional brassware.
- [ ] **Hot Water Delivery:** Confirm boiler capacity for high-demand free-standing baths & rainfall heads.
- [ ] **Pipe Chasing:** Plan floorboard lifting & wall chasing to conceal modern copper/PEX lines seamlessly.
- [ ] **Isolation Valves:** Install accessible quarter-turn valves for all period fittings.

4. DRAINAGE & WASTE LINES

- [ ] **Soil Vent Pipe (SVP):** Verify soil pipe pitch and position relative to high-level pull-chain toilets.
- [ ] **Floor Joist Alignment:** Map joist directions to avoid costly offsets for low-profile shower drains.
- [ ] **Freestanding Bath Waste:** Plan sub-floor waste traps and access panels beneath roll-top baths.
- [ ] **Anti-Syphon Traps:** Install silent, anti-syphon traps to prevent sewer gas backflow in older stacks.

5. ELECTRICS & HEATING

- [ ] **IP Ratings:** Select IP44/IP65 period-style brass or ceramic light fittings for damp zones.
- [ ] **Cast Iron Radiators:** Calculate BTU output required for high-ceiling Victorian rooms.
- [ ] **Underfloor Heating (UFH):** Install electric or water UFH matting beneath cold tile floors.
- [ ] **RCD Protection:** Ensure all bathroom circuits are RCD-protected to current standards.

6. VENTILATION & MOISTURE

- [ ] **Extractor Fan Capacity:** Install high-extraction inline fan (min 15 l/s) to protect lime plaster & wood.
- [ ] **Sub-floor Vapor Barrier:** Tank wet areas and insulate suspended timber floors to prevent draft.
- [ ] **Window Condition:** Restore timber sash windows with obscure glass or moisture-resistant shutters.
- [ ] **Humidity Controls:** Fit automatic humidistat sensors for continuous moisture extraction.

7. SANITARYWARE & BRASSWARE

- [ ] **High-Level Cistern:** Ensure wall anchors are rated for heavy ceramic or cast cisterns.
- [ ] **Basin & Vanity Support:** Confirm wall framing for heavy console basins or marble-top vanities.
- [ ] **Finish Consistency:** Match brassware finishes (Unlacquered Brass, Chrome, Nickel) across all valves.
- [ ] **Thermostatic Controls:** Fit anti-scald thermostatic valves into exposed shower rigid risers.

8. STORAGE & LAYOUT

- [ ] **Recessed Storage:** Construct tiled wall alcoves inside shower enclosures for toiletries.
- [ ] **Freestanding Furniture:** Position bespoke linen cabinets without blocking traditional door swings.
- [ ] **Mirror & Lighting:** Position wall sconces at eye level alongside ornate gilt or timber mirrors.
- [ ] **Clearance Zones:** Ensure at least 600mm clearance in front of toilets and basins for comfort.

FREQUENTLY ASKED QUESTIONS

Q: Can my suspended wooden floor support a heavy cast iron bath?
A: A filled cast iron tub with water and bather can weigh over 300–400kg. Joists should be inspected and reinforced with sister joists or marine plywood subfloors prior to installation.

Q: How do I prevent condensation on original Victorian brick walls?
A: Use breathable tanking membranes, continuous inline mechanical ventilation, and insulated tile backer boards (such as Wedi or Marmox) over exterior-facing walls.

CG BATHROOMS LIMITED • Estd. 2004 • Web: cgbathroomslimited.co.uk • Expert Heritage & Luxury Renovations